

Operation Guide

See attached operation manual for details.

Sheenus ZERO

Ultrasonic Polisher



1 Power ON: Press [Main power switch]

The LED on the control panel lights up.

2 Mode selection: Select [CLAMP key] or [UNCLAMP key]

The LED of the selected key lights up.



■ CLAMP mode (low power)

for ceramic fiber grindstone
(also used for one piece tool)



■ UNCLAMP mode

for electroplated diamond file
(One piece tool)

3 Power level adjustment: Press [DOWN key] or [UP key]

Displays the power level.
(Can be adjust during vibrating)



DOWN key

MIN



MAX



UP key

4 Startup: Press [ON / OFF key] or use the foot switch

The ON / OFF key and the LED on the handpiece light up when starting up.



When using the foot switch

- Factory default setting: Pressing the foot switch to start and releasing it to stop.
- The setting can be changed to pressing the foot switch to start and pressing it again to stop. See attached operation manual to check how to change the setting.

If it is activated by a foot switch, it can only be stopped by a foot switch. See reverse side for connecting.

Setup Guide

See attached operation manual for details.

Sheenus ZERO

Ultrasonic Polisher


Bundled items




• Controller



• Main power cord



• Handpiece



• Foot switch



• Electroplated diamond file



• Ceramic fiber grindstone
Clamp with the tip holder
(Flat) for use.



• Tip holder (Flat)

• Wrench: 2 pcs.

• Hexagon wrench

• Tip holder (Round)

• Fuse

• Tool box

• Operation Manual

1 Connecting the cords to back of controller

Main power cord



Back of controller



Handpiece



Align each
● marks and
insert the plug.

Foot switch



2 Remove the test horn

2-1

Turn the protector sleeve and remove it.



2-2

Remove the test horn using attached two wrenches.



3 Tool installation

A

Electroplated diamond file
(One piece tool)



Tighten firmly using attached two wrenches



B

Ceramic fiber grindstone



1. Attach the tip holder to the handpiece and tighten firmly with two wrenches.
2. Insert the ceramic fiber grindstone into the tip holder(①) and tighten the set screw firmly with the attached hexagon wrench(②).



Common to A and B

Insert the protector sleeve into the handpiece and turn it to install it.

*Always make sure that the protector sleeve is installed before using the handpiece, as using the handpiece without it may result in burns.

